

BEFORE FLIGHT

OXYGEN.....TEST,100%
 INSTRUMENTS.....HDG__,ALTIMETER__
 PARKING BRAKE.....SET
 FUEL CONTROL SWITCHES.....CUTOFF

BEFORE START

COCKPIT PREPARATION.....COMPLETED(BOTH)
 PINS.....REMOVED
 ADIRS.....NAV
 FUEL QUANTITY.....KG/LB
 COCKPIT DOOR.....CLOSED AND LOCKED
 PASSENGER SIGNS.....ON
 MCP.....V2__,HDG__,ALT__
 TAKEOFF SPEEDS.....V1__,VR__,V2__
 ALTIMETER.....SET(BOTH)
 CDU PREPARATION.....COMPLETED
 TAKEOFF BRIEFING.....COMPLETED
 BEACON.....ON

BEFORE TAXI

ANTI ICE.....
 RECALL.....CHECKED
 AUTOBRAKE.....RTO
 F/CTL.....CHECKED
 GROUND VEHICLES.....CLEARED
 APU.....
 TRIM.....UNIT,0.0
 ATC FREQUENCY.....SET

BEFORE TAKEOFF

FLAPS.....
 TAKEOFF RWY.....APPROVED(BOTH)
 CABIN CREW.....NOTIFY
 TCAS.....TA OR TA/RA
 PACKS.....SET AS REQUIRED
 EXTERIOR LIGHTS.....SET AS REQUIRED

AFTER TAKEOFF/CLIMB

LANDING GEAR.....UP
 FLAPS.....RETRACTED
 PACKS.....ON
 ALTIMETER.....STD SET(BOTH)

BEFORE DESCENT

RECALL.....CHECKED
 AUTOBRAKE.....
 LANDING DATA.....VREF__,MINIMUM__
 APPROACH BRIEFING.....COMPLETED

APPROACH

PASSENGER SIGNS.....ON
 ALTIMETER.....SET(BOTH)
 MINIMUM.....SET(BOTH)

LANDING

CABIN CREW.....NOTIFY
 AUTOBRAKE.....SET AS REQUIRED
 SPOILERS.....ARMED
 LANDING GEAR.....DOWN
 FLAPS.....

AFTER LANDING

FLAPS.....UP
 SPOILERS.....DISARMED
 APU.....SET AS REQUIRED
 RADAR.....OFF/STBY
 WINDSHEAR PREDICTION SYSTEM.....OFF

PARKING

ENGINES.....OFF
 HYDRAULIC SYSTEM.....SET
 FUEL PUMPS.....OFF
 WINDOW HEAT.....OFF
 PARKING BRAKE.....
 FUEL CONTROL SWITCHES.....CUTOFF
 PASSENGER SIGNS.....OFF
 EXTERIOR LIGHTS.....SET AS REQUIRED

SECURING THE AIRCRAFT

IRS.....OFF
 EMERGENCY LIGHT.....OFF
 PACKS.....OFF
 APU AND BATTERY.....OFF

飞行前

氧气.....测试, 100%
 飞行仪表.....航向__, 高度表__
 停留刹车.....调定
 燃油控制电门.....关断

起动前

驾驶舱准备.....完成(两人)
 起落架销子和堵盖.....已移除
 ADIRS.....NAV
 燃油量.....KG/LB
 驾驶舱门.....关闭并锁定
 旅客信号牌.....开
 MCP.....V2 __ HDG __ ALT __
 起飞速度.....V1 __ VR __ V2 __
 气压基准.....__调定(两人) 飞行前
 CDU 准备.....完成
 起飞简令.....完成
 防撞灯.....开

滑行前

防冰.....
 再现.....已检查
 自动刹车.....RTO
 飞行操纵.....已检查
 地面设备.....移开
 APU.....
 配平.....__单位, 0.0
 ATC 频率.....调定

起飞前

襟翼.....
 起飞跑道.....__证实(两人)
 客舱机组.....通知
 TCAS.....TA 或 TA/RA
 组件.....按需
 外部灯光.....按需

起飞后/爬升

起落架.....收上
 襟翼.....收上
 组件.....开
 气压基准.....__调定(两人)

下降

再现.....已检查
 自动刹车.....
 着陆数据.....VREF __, 最低标准__
 进近简令.....完成

进近

旅客信号牌.....开
 气压基准.....__调定(两人)
 最低标准.....__调定(两人)

着陆

客舱机组.....通知
 自动刹车.....按需
 减速板.....预位
 起落架.....放下
 襟翼.....

着陆后

襟翼.....收上
 扰流板.....解除预位
 APU.....启动
 雷达.....关/待命
 风切变预测系统.....关

停机

发动机.....关
 液压面板.....调定
 燃油泵.....关
 风挡加温.....关
 停留刹车.....
 燃油控制电门.....关断
 旅客信号牌.....关
 外部灯光.....按需

安全离机

IRS.....关
 紧急灯光.....关
 组件.....关
 APU 和电瓶.....关